

23. Replace used engine oil and filter with Mobile 1 10w30 or similar
24. The oxygen sensor circuit needs to be bridged out. This can be done in the wiring harness or at the diagnostic connector located at the the left side of motor. OX1 and OX2 needs to be bridged out
- ✓ 25. Install additional injectors and Haltech F5. It is recommended that the brain be mounted inside of vehicle and wires connected as per instructions supplied, red connects to switched 12 volts supply I.E. Ignition coil positive. Black must be properly grounded. Brown must be connected to coil negative.
- × 26. Install fuel hoses with supplied clamps and tees
27. the fuel is connected to the pressure side of the fuel system and original hose must be cut and installed with tees and clamps supplied.
28. Start engine
29. Check for leaks (oil, water,exhaust)
30. Testdrive car making sure boost pressure doest not exceed 6 to 7 PSI and absolutely no detonation or pinging noise is heard. Premium unleaded fuel only (93 octane or higher recommended)